

TooAir

TC-100

Body Worn Camera

User manual



1 Welcome

Thank you for purchasing this TooAir product

More information can be obtained on the TooAir website at

www.tooair.com.au

1.1 Product features

- Built-in high-performance codec chip.
- Audio recording in the ACC format
- Supporting 2304X1296 30P video recording
- One-key audio recording: Just press the audio recording key to start recording, and then press this key again to save the recorded audio.
- One-key video recording: Just press the video recording key to start recording, and then press this key again to save the recorded video.
- Wi-Fi remote control: When connected to a mobile phone, this product can be controlled to produce videos and audio, take photos, and support online play, local download and sharing.
- Character superimposition: All videos and photos can be superimposed with time, product number, user number, etc., and such superimposed information cannot be edited, making them more reliable as legal evidence.
- Using high-speed USB 2.0 for quick access to audio recording files and data.
- Supporting file sharing.
- Using high-speed Type-C for quick access to audio recording files and data.
- This product can be used as an MTP storage device for maximum compatibility.

2 Important Notice

2.1 Safety

Notice


- Protect the cables from being pinched, particularly at

Warning


- Special Announcement: Before using the product, please read the Manual carefully. The Company shall not be held liable for any data loss due to incorrect manual operation or force majeure. We specially recommend that users make additional copies of the files in the device.
- Images are for reference only. TooAir reserves the right to change the colour/appearance/design and specifications without prior notice

Your Device

What's in the box



Overview



- 1 USB interface
- 2 Video recording/Power on/Power off key
- 3 Audio recording/Power on key
- 4 Camera Lens
- 5 LED indicator
- 6 Reset hole

Commonly used function

Power on/off

In the off mode, hold down the video/audio recording key to start, and enter the corresponding working state, hold down the video recording key to shut down.

Audio recording

In the off mode, hold down the audio recording key for 4~5 seconds to start this unit and the green LED flashes. After releasing the key, wait for about 8~9 seconds; the audio recording will begin when a beep sound is heard, and the green LED stays on. During audio recording, press the audio recording key to save the recorded audio. Hold down the video recording key when the green LED flashes to shut down this unit.

Video recording

In the off mode, hold down the video recording key for 4~5 seconds to start this unit and the green LED flashes. After releasing the key, wait about 8~9 seconds, the video recording will begin when a beep sound is heard and the LED changes to red and stays on. During video recording, press the video recording key to stop and save the recorded video. The LED will flash green (standby). To record a new file, quickly press the video record key, and the recording will start in 2 seconds. Hold down the video recording key when the green LED flashes to shut down the camera.

Wi-Fi connection

1. In the off mode, hold down the audio recording key for about 14 seconds until the LED flashes green and then alternating green and red. Wi-Fi is enabled, and you can open the mobile app for connection and use; if no mobile phone is connected in 3 minutes, Wi-Fi will be shut down, and then this unit will be shut down automatically. After a successful connection, the green indicator will flash, and this unit will enter standby mode.
2. In the standby mode, hold down the audio recording key for 6 seconds until the LED flashes alternately green and red. Wi-Fi is enabled, and you can open the mobile app for connection and use. If no mobile phone is connected in 3 minutes, Wi-Fi will be shut down, and then this unit will be shut down automatically; after a successful connection, the green indicator will flash, and this unit will enter the standby mode.

Default Wi-Fi password: 88888888

Charging

Use a USB data cable to connect this unit to the PC or 5v USB port.

In the off mode, the LED will illuminate blue normally during charging and will go out when the unit is fully charged.

In the on mode, the blue indicator is normally on during charging, and the original indication will be maintained.

Indicator status

Standby: The green indicator flashes.

Audio recording: The indicator shows a solid green light.

Video recording: The indicator shows a solid red light.

Charging: The indicator is blue (the green indicator flashes for several minutes) and will go out when this unit is fully charged.

Low Battery: The indicator rapidly flashes red, and then the unit shuts down

Memory Full: The indicator flashes red and green alternately, and the camera will make a “beep” “beep” sound

PC Connection

As a storage device, this product can be connected to the PC using a USB data



Note

When this unit is connected to the PC, the blue indicator is normally on.

- When moving a file into or from this product, please do not disconnect this product from the PC, or the file may be damaged.

14 Download and install android APP

App Download and Setup



- Android mobile phones can scan this QR code to download and set up the app. For all authority checking popups during setup, please click “Yes”, otherwise the app will be unusable. For some mobile phones, the “mobile network” should be shut down for connection and use.

Connection and Use

Step 1:

Open Wi-Fi on this unit, and enable Wi-Fi using Method 1 or 2 in the “Wi-Fi Connection” instructions.

Step 2:

Open the downloaded mobile app, and click on “Start Connection” on the mobile app screen, then the prompt “Make sure mobile Wi-Fi has been connected” will pop up; click on “Enter” to go to the Wi-Fi connection list, connect the **TC-100xxxxx** network manually, and enter the password “**88888888**”; after a successful connection, this unit will beep, and the app will enter the preview screen automatically.

Audio recording

The app settings include: 1) video recording resolution; 2) loop overwriting; 3) pixel setup; 4) policeman ID setup; 5) device ID setup; 6) time setup; 7) formatting; and 8) factory reset.

- Audio recording via the app: Connect to the app, select “Audio Recording” on the main screen, and then press the “Audio Recording” icon to begin recording; press the “Audio Recording” icon again to save the recorded audio. (During audio recording, the screen is in the preview mode.)
- Photo taking via the app: Connect to the app, select “Photo Taking” on the main screen, and click on the “Photo Taking” icon of the app for photo taking.
- Video recording via the app: Connect to the app, select “Video Recording” on the main screen, and then press the “Video Recording” icon to begin recording; press the “Video Recording” icon again to save the recorded video.
- File download via the app: When the mobile app is connected to this unit, the app can download video, audio and photo files in this unit to the mobile phone. Select the file to be downloaded, and click the “Download” icon of the app. After the download completes, “Download Successful” will be displayed.

*: In the video recording / audio recording mode, click on the “Star” icon to mark any key file.

18 Warranty

This warranty against defects is given by Too Air Pty Ltd ABN 58 615 252 536

1. Consumer guarantees

1.1 Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

1.2 To the extent we are able, we exclude all other conditions, warranties and obligations which would otherwise be implied.

2. Warranty against defects

2.1 This warranty is in addition to and does not limit, exclude or restrict your rights under the Competition and Consumer Act 2010 (Australia) or any other mandatory protection laws that may apply.

2.2 We warrant our goods to be free from defects in materials and workmanship for the warranty period of 12 months from the date of original sale. Subject to our obligations under clause 1.2, we will at our option, either repair or replace goods which we are satisfied are defective. We warrant any replacement parts for the remainder of the period of warranty for the goods into which they are incorporated.

Product type warranty

2.3 To the extent permitted by law, our sole liability for breach of a condition, warranty or other obligation implied by law is limited

(a) in the case of goods we supply, to any one of the following as we decide -

- (i) the replacement of the goods or the supply of equivalent goods;
- (ii) the repair of the goods;
- (iii) the cost of repairing the goods or of acquiring equivalent goods;

(b) in the case of services we supply, to any one of the following as we decide –

- (i) the supplying of the services again;
- (ii) the cost of having the services supplied again.

2.4 For repairs outside the warranty period, we warrant our repairs to be free from defects in materials and workmanship for three months from the date of the original repair. We agree to re-repair or replace (at our option) any materials or workmanship which we are satisfied are defective.

2.5 We warrant that we will perform services with reasonable care and skill and agree to investigate any complaint regarding our services made in good faith. If we are satisfied that the complaint is justified, and as our sole liability to you under this warranty (to the extent permitted at law), we agree to supply those services again at no extra charge to you.

2.6 To make a warranty claim you must before the end of the applicable warranty period, return the goods you allege are defective, provide written details of the defect, and give us an original or copy of the sales invoice or some other evidence showing details of the transaction.

2.7 Send your claim to:

Tooo Air Pty Ltd.
Suite 142, 95-97 Grafton St
Bondi Junction, NSW 2022.
Tel: (02) 9157 0540
Email: info@toooair.com.au

3. This warranty does not cover

This warranty will not apply in relation to:

- (a) goods modified or altered in any way;
- (b) repairs performed other than by our authorised representative;
- (c) defects or damage resulting from misuse, accident, impact or neglect;
- (d) goods improperly installed or used in a manner contrary to the relevant instruction manual; or
- (e) goods where the serial number has been removed or made illegal.

4. Warranty period

The warranty on the ToooAir TA-100 BWC and Power Adapter is 12 Months. No repair or replacement during the warranty period will renew or extend the warranty period past the period from the original date of purchase.

ToooAir

Tooo Air Pty. Ltd.

Suite 14, 95-97 Grafton St

Bondi Junction

NSW 2022

Phone: +61 2 9157 0540

Web: www.toooair.com.au

Email: info@toooair.com.au

